









OPENING THE DOOR BY ORIGINAL IGNITION KEY WIRING GUIDE FOR MB SPRINTER – PAGE 01

Picture 1-2	 <p>Find the bundle of cable under the right side seat in front cab</p>	
Picture 3-4	 <p>Find blue-black and blue-brown cables from the bundle and peel them off. Then connect them to the proper cables coming from electronic control unit (pictures 2-3-4-5-6-7-8).</p>	 <p>Connect Yellow-White cable coming from sliding door electronic control unit to blue-brown cable from the bundle and Yellow-Black cable from electronic control unit to the blue-back from the bundle.</p>
Picture 5-6		
Picture 7-8		

**OPENING THE DOOR BY ORIGINAL IGNITION KEY WIRING GUIDE FOR
MB SPRINTER – PAGE 02**

Picture
9-10

